

Receptacle

INSTALLATION INSTRUCTIONS

ENERGYLITE



IMPORTANT: Read ALL instructions before starting installations.







CAUTION: To reduce risk of shock, **TURN OFF ELECTRICAL SUPPLY** before installing/servicing fixtures.

WARNING: Fixture must be installed in accordance of National Electrical Code (NEC) and /or any local codes.
Failure to do so may result in serious injury and/or damage to the fixture.

SAFETY INSTRUCTIONS

- **Verify that supply voltage matches the voltage marked on the fixture label. Failure to do so may result in damage to the light fixture and will void the warranty.**
- Observe and follow all label information and instructions regarding dry, damp and wet location listings, proper type and wattage, warnings of installation near combustible materials and or insulation.
- Be sure to connect ground wire to prevent electric shock or other potential hazards.
- Product must be installed in a manner consistent with the intended use and in compliance with national electrical codes and local codes.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- These instructions do not purport to cover all details or variations of installations, operation or maintenance. Contact Solais Lighting Group if a specific problem or clarification needs to be addressed that is not covered by these instructions.

RECOMMENDED TOOLS


Wire Nuts 	Wire Cutter/Stripper 	Hardware <ul style="list-style-type: none">• ¼ - 20 hardware• #8 - 32 x ½" screws• ⅝ - 16 x 2" bolts 	Drill and Paper Hole Diagram 	Torx T-15 and #2 Phillips 	⅜" and ⅝" Ratchet/Socket & torque wrench 
--	---	--	---	--	---

WIRING DIAGRAM



INSTRUCTIONS:

- **Photocontrol Receptacle Adjustment**
 - Loosen (2) 6-32 screws on receptacle cover.
 - Rotate center of receptacle with screw driver so that the arrow points in the north direction.
 - Refasten receptacle cover with (2) 6-32 flathead screws to 8-12 in-lbs.
 - Install photocell or shorting cap (not supplied).



5017-000013 Rev A